

# Aero

This indoor/outdoor modular backwall is one of the most versatile on the market. With adjustable height and angles, there are multiple configurations possible. It is available in a complete kit or a la carte to create more combinations.



## Features and Benefits

- Stable bases and articulated design allows for multiple configurations
- Can be used for trade show displays or outdoor marketing
- Can be purchased in a kit or a la carte
- Easy to assemble and transport

## Additional Information

### Shipping Information

Upright Box: 47" x 4.5" x 4", 7 lbs  
 1200mm Cassette: 53" x 5" x 4", 10 lbs  
 Base Box: 18" x 18" x 3", 9lbs

### Graphic Information:

Graphic Substrate: Smooth Vinyl, Cotton, or Anti-Curl Vinyl

Included in basic kit: four bases, 4 uprights, 3 1200 mm banners In full kit: add 2 lights, OCH hard case

Pole Diameter: 3.25" at widest point

### Graphic Dimensions:


#### Center Graphic:

Full: 47"w x 79.125"h  
 Half: 47"w x 59.375"h  
 Half (pulling down from fully extended poles): 47"w x 37"h  
 Quarter: 47"w x 41.375"h

#### Side Graphics:

Full: 47"w x 79.125"h  
 Half: 47"w x 59.375"h  
 Half (pulling down from fully extended poles): 47"w x 37"h  
 Quarter: 47"w x 41.375"h

\*Add 6" bleed at the top and 3.75" bleed at the bottom



**1**



**2**



Unscrew wing-nut located at the bottom of each pole

**7**



Pull graphic down from cassette by rail edge

**8**



Fasten graphic rail edge to hanger at bottom of pole

**3**



Attach poles to disk base with wing-nut

**4**



Insert graphic cassette/rail hangers in the slots at top of poles where graphic cassettes will be

**9**



simply turn the graphic tensioner clockwise to create more tension

**5**



Adjust poles to desired height by using the release buttons on sides of poles

**6**



Hang graphic cassettes by inserting opening at end of cassette over rail hangers at top of pole

