


Wireless Infrared Controller



Infrared Eye
Point toward little "eye" on controller to make changes to colors etc... (like most t.v. remotes)

Dimmer
Push multiple times to make sign less bright

Increase Brightness
Push multiple times to make sign more bright

Pause / Play
Press when sign is changing colors to pause the sign on a particular color or press to start sign rotating through the colors again.

On / Off
Push to turn sign on or off

Static Color Chart
Push to choose one of 20 colors.

Increase Speed
Press to increase the speed of color change when jumping or fading between colors

Decrease Speed
Press to decrease the speed of color change when jumping or fading between colors

Do It Yourself (DIY)
Make your own static color. This allows you to make up to six different unique colors.

Jump and Fade
Causes the colors to jump and then fade between colors.(combination)

Flash White
Press to make sign flash on and off (white color only)

- Steps:**
1. Press DIY 1 button
 2. Press either the red, green, or blue arrows to increase or decrease the amount of each color till you achieve desired color "mix".
 3. Press DIY 1 button again to "lock" in the color that you just created.
 4. Now anytime you want that particular color you can just press DIY 1 button
 5. You can program each of the (6) DIY buttons to have a unique color.

7 Color Fade
Press to have sign fade between 7 different colors

3 Color Fade
Press to have sign fade between 3 different colors. (Red, Green and Blue)

3 Color Jump
Press to have sign jump between red, green and blue.

7 Color Jump
Press to have sign jump between 7 different colors

General Notes:

Some buttons have many "steps" that require you to press the button several times to achieve any noticeable change. You can sometimes hold the button down to make multiple changes in a row. This especially applies to the DIY button and the Increase and Decrease buttons. Sometimes the remote is shipped with a small plastic tab at the bottom of the controller that blocks the power to the remote during shipping. You should pull this tab out before attempting to operate the remote. The remote takes a Cr2025 battery.